

Recording Digital Channels Using an Analog VCR



← Analog TV


How it works

This set up allows you to continue to use your analog VCR to record and play back digital channels off the air. The playback will not be in high definition format since VCR machines use analog technology.

Connect the VCR to your analog TV with the antenna cable from your VCR. Connect an antenna to your DTV Converter Box using the antenna cable input. The Converter Box should be connected to the VCR using AV Cables. Set the VCR Tuner to “**Line**” or “**Video**” input and the TV tuner to Channel 3. These settings should never be changed.

You will not be able to program the VCR to change channels when recording at some future time. You will be able to use the clock timer to begin recording at a pre-selected time and date but the DTV converter must be left on and be manually set to the channel to be recorded.

Antenna Cable



AV Cables (Yellow, Red & White)



DTV Converter

Antenna Cable



Indoor or Outdoor Antenna

